



## **CM/CW Series Trijicon Night Sight Installation Instructions**

### **Contents of package:**

1. Front sight
2. Rear sight
3. Phillips head screw
4. Loctite
5. Instructions

### **Tools required:**

1. Pick or small pin punch (not included)
2. Vice grips or similar tool (not included)
3. Phillips screw driver (not included)
4. Loctite

**\*All of the following steps should be done with care on a non-marking, non-abrasive surface by a certified gunsmith.\***

### **DISSASSEMBLY OF FIREARM:**

1. With the pistol pointed in a safe direction, remove the magazine and ensure that there are no rounds in the chamber. Visually inspect to ensure that the pistol is completely unloaded.
2. Remove the slide from the pistol.
3. Remove the barrel and recoil spring assembly from the slide.

### **REMOVAL OF THE EXISTING FRONT SIGHT:**

1. Using a small set of vice grips (or similar tool), being careful not to make contact with the slide, grip the front sight and pull forcefully to remove the upper half of the sight from the slide.
2. Using a pick or very small pin punch, push the remaining portion of the polymer posts out of the slide from the top of the slide. Be careful not scratch the top of the slide.
3. Turn the slide over and ensure there is no remaining polymer in the front sight holes of the slide. If there is, gently remove it using the pick or small pin punch.

### **REMOVAL OF THE EXISTING REAR SIGHT:**

1. **DO NOT USE A PUNCH TO REMOVE REAR SIGHT.** THIS WILL DAMAGE BOTH SIGHT AND SLIDE.
2. Place the slide in a non-marking sight press.
3. With the muzzle end faced away from you, push the rear sight from left to right out of the slide. Be careful not to scratch or damage any part of the slide.

### **INSTALLATION OF THE TRIJICON FRONT SIGHT:**

1. Ensure the slide does not contain any metal or polymer burrs. If burrs exist, remove before installation of sight.
2. Place a small amount of Loctite in the threaded hole of the front sight.
3. Place the front sight into the front sight holes of the slide.
4. Turn slide over
5. Carefully thread screw into threaded hole of front sight. Do not cross thread screw.
6. Hand tighten until fully seated in the threaded hole. Be careful not to strip screw head.
7. Front sight should be flush to the top of the slide. There should be no movement of front sight once installed properly.
8. Let slide sit for 24 hours allowing Loctite to cure.

### **INSTALLATION OF TRIJICON REAR SIGHT:**

1. **DO NOT USE A PUNCH TO INSTALL REAR SIGHT.** THIS WILL DAMAGE BOTH SIGHT AND SLIDE.
2. Place the slide in a non-marking sight press.
3. With muzzle end faced away from you, push the rear sight into the slide from right to left. Be careful not to scratch or damage any part of the slide.

## **DISCLAIMER NOTICE:**

**Failure to properly install sight systems on your Kahr pistol may result in personal injury, death, damage to the sight system, or damage to your firearm. Kahr Arms is not responsible for any damages as a result of the installation of this sight system. Accordingly Kahr Arms factory warranty will void due to improper installation and or damage to the firearm.**